



1/2 The Distance From The End Of The Raised Median To The Crossroad Flowline

NOTES:

1. See detail "A" on T.S. 7-1 for pullbox installation.
2. Coil 10 feet of detector wire in pull box.
3. Install detector pairs in each lane.
4. Each loop detector shall be identified by tagging as shown in detail A.
5. All 6' x 6' loops shall have 4 turns, all others shall have 3 turns.
6. All loops shall be installed in sub-base or prior to final pavement layer.
7. Conduit For Loop Lead-in Conductors Shall Be 2" PVC.



DETAIL A



DETAIL B

DESIGN APPROVED <i>Charlie Brown</i> 7/28/85	STATE OF ARIZONA DEPARTMENT OF TRANSPORTATION DIVISION OF HIGHWAYS STANDARD DRAWINGS	REV.
APPROVED FOR DISTRIBUTION <i>[Signature]</i>	TYPICAL LOOP INSTALLATION FOR RAMP METERING	DRAWING NO. T.S. 7-4